





**How do you do it? It is quite simple?**

1. Turn on your projector.
2. Load the software that you have been provided onto your PC.
3. Use this program to configure your plain board and make it interactive.
4. Turn on the “Infrared Remote” that you have been supplied. Set the Remote at a distance to cover the projected screen on the board.
5. The “Infrared Remote” must be placed at not more than 45° angle facing the board (see detailed instructions provided)
6. The keystone markings + should appear on each corner of the projected board when the Infrared Remote is turned on.
7. Use the infrared pen that have been supplied with & touch or mark all the four + signs projected on the board. This will set the interactive area on the screen.
8. Now you are ready to use the interactive whiteboard.
9. To call up programs or write on the interactive whiteboard, just use the infrared pens like a standard mouse.





### Check list for the “DIY” package:

1. One “Infrared Remote” device with mount & re-chargeable batteries;
2. Two infrared pens with batteries;
3. Interactive software for the “Infrared Remote”;
4. Blue Tooth software;
5. One battery charger;
6. Installation manual.

### To order you “DIY” interactive package contact:

Assistive Technology NZ Ltd  
 PO Box 19048  
 Courtney Place  
 Wellington

email: [fchang802@paradise.net.nz](mailto:fchang802@paradise.net.nz)  
 Phone: (04) 971 3166  
 Mob: 0274 429 007